

CLINIC-SYSTEM RELIABLE PROTECTION FOR TEMPERATURE SENSITIVE MEDICATIONS



PERFECT PROTECTIVE PACKAGING

CLINIC-SYSTEM FOR THE RIGHT TEMPERATURE IN THE WARD

Whether pain medications, antibiotics, cytostatic drugs, or other types of medicine, hospital pharmacies need to get important medications to patients in the ward or other locations uncompromised, often in a short period of time.

OPTIMAL TEMPERATURE GUARANTEED

The tailored segment solution for hospitals ensures that life-saving, temperature sensitive medications such as cytostatic drugs reach the ward at the appropriate temperature. This is made possible by the proven phase change material (PCM) technology of the accumulators made

of robust, hard plastic, whose melting range is located precisely inside the temperature ranges of 2 to 8°C or 15 to 25°C.

The Clinic-System is the ideal solution for more than just the optimal temperature. The boxes for temperature-controlled transport close up tightly and feature additional sealing with a lining and closure seal, thus ensuring reliable leakage protection at all times. Because the overall system solution is made of durable EPP, it can be used repeatedly, effectively cleaned, and still maintains its clean appearance in everyday hospital use.

THE BENEFITS OF THE CLINIC-SYSTEM

- JUST THE RIGHT TEMPERATURE: OPTIMAL TEMPERATURE RANGE THANKS TO PCM ACCUMULATORS
- LEAKPROOF: BOXES CLOSE UP TIGHTLY AND FEATURE ADDITIONAL SEALING
- ROBUST: EPP BOXES CAN BE USED REPEATEDLY •
- CLEAN: THE MATERIAL CAN BE EFFECTIVELY DISINFECTED •
- STRAIGHTFORWARD: COLORED MARKINGS REVEAL CONTENTS AND APPLICATION AT A GLANCE
- COST-EFFECTIVE: REPEATED USE REDUCES COSTS AND CONSERVES RESOURCES •
- SIMPLE: ALL SYSTEM COMPONENTS CAN BE REORDERED INDIVIDUALLY BUT ALSO FIT TOGETHER
- PRACTICAL: ORDERS CAN BE PICKED AND PLACED DIRECTLY IN THE PLASTIC TRAY SAVING TIME WHILE THE ACCUMULATOR REACHES THE OPTIMUM TEMPERATURE BEFORE ALSO BEING PLACED INSIDE THE BOX

TECHNICAL SPECIFICATIONS CLINIC-SYSTEM

	10 l	24 l	10 l	24 l
External dimensions in mm	417 x 385 x 370	697 x 385 x 370	417 x 385 x 370	697 x 385 x 370
Loading capacity in mm	210 x 210 x 229	490 x 210 x 229	210 x 210 x 229	490 x 210 x 229
Payload in l	10	24	10	24
Duration in hours	32	26	48	48
Temperature range	2-8°C	2-8 °C	15-25 °C	15-25 °C



Simple to Tell Apart:

Colored specks specify the application and contents of the boxes, so that, for instance, boxes for cytostatic drugs can be identified at a glance.



Lid

PCM accumulators

Liner





The system solution consists of very few, optimally coordinated components that can be used repeatedly and reordered individually. If the box needs to be replaced, the accumulators and closures can still be used.

STOROPACK - PERFECT PROTECTIVE PACKAGING

Wherever in the world you send your products, we want them to be well protected while in transit.

OPTIMUM PROTECTION WITH MEDICAL SOLUTIONS

Our insulated boxes and prequalified system solutions protect your temperature-sensitive products and ensure the optimum temperature range. Whether as disposable or robust, reusable solutions, our Medical Boxes get your products to their required destination at the right temperature.

More about Storopack Medical: www.storopack.com/medical

CONTACT US

Storopack Deutschland GmbH + Co. KG Untere Rietstrasse 30 72555 Metzingen Germany

 Asia-Pacific
 +852 3421 2392

 Europe
 +800 7867 6722

 North America
 +1 800 827 7225

 South America
 +55 11 5677 4699

www.storopack.com

info@storopack.com

